

Jabra[®]
YOU'RE ON

JABRA EVOLVE 40



User Manual

jabra.com/evolve40



A BRAND BY

GN Netcom

© 2014 GN Netcom A/S / GN Netcom US, Inc. All rights reserved.
Jabra® is a registered trademark of GN Netcom A/S. All other
trademarks included herein are the property of their respective
owners.

Made in China
MODEL : HSC017
ENC010

FCC ID: BCE-HSC017
IC: 2386C-HSC017



Declaration of Conformity can be found on
www.jabra.com/CP/US/declarations-of-conformity

1. WELCOME.....	4
2. JABRA EVOLVE 40 OVERVIEW.....	5
2.1 STEREO VARIANT	
2.2 MONO VARIANT	
3. HOW TO WEAR.....	7
3.1 LEFT OR RIGHT WEARING STYLE	
3.2 ADJUST THE HEADBAND	
3.3 POSITION THE MICROPHONE	
3.4 STORING THE MICROPHONE	
4. HOW TO CONNECT.....	10
4.1 CONNECT TO PC (WITH CONTROLLER)	
4.2 CONNECT TO MOBILE DEVICE (WITHOUT CONTROLLER)	
5. HOW TO USE	12
5.1 CALLS	
5.2 MULTIPLE CALL HANDLING	
5.3 BUSYLIGHT	
6. SUPPORT	15
6.1 FAQ	
6.2 HOW TO CARE FOR YOUR HEADSET	
7. TECHNICAL SPECIFICATIONS	16

1. WELCOME

Thank you for using the Jabra Evolve 40. We hope you will enjoy it!

JABRA EVOLVE 40 FEATURES


- Busylight on headset and the Jabra Evolve Link controller
- Discreet microphone boom-arm that integrates into the headband when not on calls
- Connects to multiple devices (smartphone or tablet) with 3.5 mm jack (plug & play)
- Superior music and voice capabilities
- Hi-Fi Sound

2. JABRA EVOLVE 40 OVERVIEW


2.1 STEREO VARIANT




CONTROLLER (JABRA EVOLVE LINK)




2.2 MONO VARIANT



Controller (Jabra Evolve Link)




3. HOW TO WEAR




3.1 LEFT OR RIGHT WEARING STYLE

The Jabra Evolve 40 can be worn on the left or right by flipping the microphone to the other side (270° limit).



3.2 ADJUST THE HEADBAND

Adjust the headband to find the most comfortable fit.




3.3 POSITION THE MICROPHONE

It is recommended to position the microphone close to your mouth (0.5 inches).




The microphone is bendable for personal preference.



3.4 STORING THE MICROPHONE


When listening to music or outdoors, the microphone can be stored in the headband groove.



4. HOW TO CONNECT

4.1 CONNECT TO PC (WITH CONTROLLER)

Fully plug the headset into the controller, and connect the controller to a USB port on the PC.




The headset jack **MUST** be fully inserted into the controller for the headset to work.

NOTE: When the headset is disconnected from the controller, any active call will be put on hold. To resume the call, reconnect the headset to the controller and manually resume the call on the PC (softphone).


4.2 CONNECT TO MOBILE DEVICE (WITHOUT CONTROLLER)

Plug the headset directly into your mobile device.







NOTE: When plugged directly into a mobile device, the overall call quality (for you and the listener) will be lower than when connected to a PC/tablet using the controller (Jabra Evolve Link).

5. HOW TO USE




5.1 CALLS

	FUNCTION	ACTION
	Answer/end call	Tap the Answer/end button
	Reject call	Double-tap the Answer/end button
	Battery and connection status	Tap the Answer/end button when not on a call
	Adjust volume	Tap the Volume up or Volume down button
	Busylight on/off	Tap the Busylight button
	Mute/unmute microphone	Tap the Mute microphone button

5.2 MULTIPLE CALL HANDLING

The headset can accept and handle multiple calls at the same time.

	FUNCTION	ACTION
	End current call and answer incoming call	Tap the Answer/end button
	Switch between held call and active call	Press and hold (2 secs) the Answer/end button
	Put current call on hold and answer incoming call	Press and hold (2 secs) the Answer/end button
	Reject incoming call, when on a call	Double-tap the Answer/end button

5.3 BUSYLIGHT


The busylight indicator on the headset and the controller indicates to others when you are busy.

MANUALLY TURN BUSYLIGHT ON/OFF

To manually activate the busylight on/off, tap the **Busylight** button on the controller. The busylight can be activated even when you are not on a call.

ENABLE/DISABLE BUSYLIGHT FUNCTION

To enable/disable the busylight function, press and hold (3 secs) **Busylight** button on the controller.



6. SUPPORT

6.1 FAQ

View the FAQs on jabra.com/evolve40

6.2 HOW TO CARE FOR YOUR HEADSET

- Always store the headset with the power off and safely protected.
- Avoid storage at extreme temperatures (above 25°C/77°F or below -20°C/-4°F). This may adversely affect the headset.

7. TECHNICAL SPECIFICATIONS

JABRA EVOLVE 40 HEADSET	SPECIFICATION
Headset weight:	Mono headset 80 g Stereo headset 113 g
Controller weight:	55 g
Headset dimensions:	Mono headset L 155.4 mm x W 58.6 mm x H 181 mm Stereo headset L 155.5 mm x W 58.6 mm x H 180.9 mm
Controller dimensions:	W 54 mm x H 14 mm
Microphones:	Noise cancelling microphone
Speaker:	28 mm Dynamic PureSound speakers (Hi-Fi)
Speaker maximum input power:	10 mW
Speaker frequency range:	70 Hz - 20 kHz
Cable length:	Controller to PC: 90 mm Headset to 3.5mm jack: 1.2 m
Operating temperature:	-10°C to 55°C (14°F to 131°F)
Storage temperature:	-20°C to 25°C (-4°F to 77°F)

